

Special Order Map

For SE and SES (T10 and T11) Series

Build Your Own Part






Model

- T10 SE Series - Airstream Mount - refer to pages 17-19
- T11 SES Series - Surface Mount - refer to pages 17-19

Reset

- 1 Automatic
- 2 Manual (Open On-Rise Only)
- 3 Single operation

Electrical Function

- 1 Open on-rise (normally closed)  (S.P.S.T.)
- 2 Close on-rise (normally open)  (S.P.S.T.)
- 3 Single pole - double throw  (S.P.D.T.)

Terminal Type

- 3 .250 quick connects - Faston (6.3mm - male)
- 4 M4 (4mm screw)
- 5 S.P.D.T.:
 .250 quick connects - Faston 6.3mm - male
 .250 quick connects - Faston 6.3mm - female
 .187 quick connects - Faston 4.8mm - male
- 6 #8-32 screw

Terminals

- 1 Horizontal
- 3 Vertical


Terminal Orientation (from mount holes) - refer to page 21

- Code 0 0°
- Code 30 30°
- Code 45 45°
- Code 60 60°
- Code 90 90°
- Code 135 135°
- Code 150 150°

Set Point (specify in °F)

Differential (specify in °F)

Example Part Number



It is the customer's sole responsibility to specify and determine the suitability of a particular control or component based on their unique individual applications and requirements

(714) 917-1333 • (800) 257-3526 • FAX (714) 917-1355 • E-mail: sales@selcoproducts.com